
ZTE



5G NR Air Interface Protocol Principle

Contents

Protocol Architecture

Physical-Layer Protocols

MAC-Layer Protocols


RLC-Layer Protocols

PDCP-Layer Protocols


SDAP-Layer Protocols

RRC-Layer Protocols


5G Overall Architecture



Radio Protocol Architecture



Control Plane Protocol Stack



User Plane Protocol Stack

For more learning Materials,please refer to

https://euniv.zte.com.cn

- If you have registered for the ZTE certification exam, please log in to ZTE e-Learning with your email to take the exam. If you encounter account login issues, please contact: ucs@zte.com.cn.
- If you have not registered for the ZTE certification exam, contact the training organizer to activate a learning account for you.